Product Overview

Secure Communication Made Easy

	SiteManager 1029/3229	SiteManager 1039/3239	SiteManager 1429/3429	SiteManager 1439/3439
Managed Ethernet device ports	1	1	4	4
Integrated 3G/GPRS-EDGE Uplink	No	Yes	No	Yes
3G/GPRS-EDGE Uplink via USB	Yes	No	Yes	No
I/O ports (Input/Output)	2/2	2/2	2/2	2/2
Device access via Serial port	Yes	Yes	Yes	Yes
Device access via USB port	Yes	Yes	Yes	Yes
DIN mountable	Yes	Yes	Yes	Yes
Number of Device Agents (default/max) — Model 10xx/14xx: / Model 32xx/34xx:	2/5 5/100	2/5 5/100	2/5 5/100	2/5 5/100
Use as data logging gateway	Yes	Yes	Yes	Yes
Use as SMS gateway (Serial and Ethernet)	No	Yes	No	Yes
Power feed	12-48 V/DC	12-48 V/DC	12-48 V/DC	12-48 V/DC

	SiteManager Soft for Windows	SiteManager PC for Windows
Supports 32 and 64 bit Windows	Yes	Yes
Device agents (default/max)	50/100	10/10
Access to programs on the PC	Yes	Yes
Access to devices in the network	Yes	No
Device access via Serial port	No	No
Device access via USB port	No	No

Secomea BASIC START Package
1 x SiteManager
1 x LinkManager License
1 x Hosted GateManager BASIC Account

GateManager BASIC is a **FREE** M2M server hosted by Secomea

|	LinkManager	LinkManager Mobile
Supports 32 and 64 bit Windows	Yes	Yes
Support iPhone, iPad and Android OS	No	Yes
"VPN like" access to equipment	Yes	No
Access to Web enabled devices	Yes	Yes
Access to Remote Desktop (VNC/RDP)	Yes	Yes
Access to USB and Serial devices	Yes	No

Remote Access to Industrial Equipment

- Easy Setup
- Central Administration
- Firewall Friendly
- State-of-Art Security
- Fast Return On Investment

Smedeholm 12-14, DK-2730 Herlev, Denmark, Tel.: +45 8870 8650
info@secomea.com, www.secomea.com

secomea

www.secomea.com

# Get started in less than 15 minutes ·····➤ with the BASIC START Package

① SiteManager

Install **SiteManager** and enter the GateManager Server that it should connect to

✓ No need for open ports in the Firewall
✓ No need for fixed IP addresses
✓ No need for involving local IT
✓ No need for configuration locally

PLC
PC/Server
HMI/Panel
Camera
etc.

via
- Ethernet,
- Serial
- USB

Device Agents

SiteManager

SCADA Systems

GateManager

② LinkManager

Install the **LinkManager** client and the received access certificate on your PC

Login and browse to a Site, a SiteManager or a specific device

Click to connect to a remote device

You are now Online

LinkManager

UPGRADE to GateManager PREMIUM..

.. and get advanced GateManager administration features ..

✓ Automatic configuration backup
✓ Bulk-upgrade SiteManager firmware
✓ View audit logs
✓ Create email/SMS alerts based on device status
✓ Remotely access Web GUI of all SiteManagers
✓ Fine-grain user access for specific sites or equipment

GateManager Administration

③ .. or start your **LinkManager Mobile** for accessing Web- or VNC/RDP Remote Desktop enabled devices

LinkManager Mobile